# **TrueSTEAM**<sup>™</sup> A Quantum Leap In Application And Performance



MOUNTS IN MINUTES — Requires only a 1-3/4" cut into ductwork and mounts on a separate, lightweight bracket (included) for accurate leveling.



**APPLICATION FLEXIBILITY** — Can be remotely mounted up to 20 feet from the system.



**EASY MAINTENANCE** — No tools required to access and clean tank, which can save time on your annual contract service calls.


**INDEPENDENT OPERATION** — Provides humidity independent of equipment operation, allowing homeowners to reach their desired humidity setpoints — regardless of air temperature.

**INCOLOGY 600 HEATING ELEMENT** — A material designed to inhibit mineral build-up.

**EXCLUSIVE SUPPORT** — Honeywell supports you with a 5-year warranty, a toll-free hotline (1-800-328-5111), local experts, training, free literature, Contractor PRO<sup>™</sup> rewards and more.



**DUAL-ACTION WATER VALVE** — Solenoid design automatically fills and drains when needed to prevent debris build-up in the tank.





water levels.

PATENTED<sup>\*</sup> CONDENSATE COLLECT DOME AND NOZZLE -Prevents water from condensing out of the unit, delivering only true steam into the airflow.

**COMMON-SENSE INTERFACE** — LED lights indicate when system is running or needs service. Lights also provide feedback to the installer during installation.

**CLEAN, PROFESSIONAL INSTALLATION** — Push terminals for easy wiring (no screwdriver required) are routed through an interior harness so no wires are exposed.

\* Patent pending



www.forwardthinking.honeywell.com

FAIL-SAFE WATER SENSING — Multiple sensors (two low, two high and one ideal) sit in a separate compartment to accurately monitor

**ECO-FRIENDLY** — Uses up to 70 percent less water to produce even more of moisture than traditional whole-house humidifiers. Plus, humidified air feels warmer, so your customers will be able to turn their thermostats down to help reduce heating bills.









# **TrueSTEAM**<sup>™</sup> A Quantum Leap In Application And Performance





## **Control Options**

Choose the humidity control option that is right for your customer. TrueSTEAM<sup>™</sup> humidification systems can be controlled using:







### Which Model Do I Need?

#### SQUARE

ARI\* Re TrueS

#### Ti TrueS Tr TrueS Tr

Part Nu HM512V HM512D HM509V HM509D HM509H HM506V HM506D

#### **Manual Humidity** Control

For simple control of humidity levels only. Allows homeowner to adjust settings as needed.

VisionPRO<sup>®</sup> IAQ Total

Home Comfort System

temperature, humidification,

TrueIAQ<sup>™</sup> Indoor Air

For automatic control of humidity

based on both inside and outside temperatures. Provides homeowner

with advanced humidity sensing

and programming capabilities.

from a single device.

**Quality Control** 

dehumidification and ventilation

For integrated control of the home's

Part Nu 5002491 5002491

HM506H

#### www.forwardthinking.honeywell.com

Choose the Honeywell TrueSTEAM model that's right for your application using the table below.

E FEET OF SPACE	500	1,000	1,500	2,000	2,500	3,000
commended Output elivery (GPD)	0.1	2.2	4.4	6.5	8.6	11.7
STEAM HM512 — rue 12 Gallons						
STEAM HM509 — True 9 Gallons						
STEAM HM506 — Tue 6 Gallons						

TrueSTEAM Humidification System				
umber	Description			
/PIAQ	12-GPD TrueSTEAM with VisionPRO IAQ control			
)G115	12-GPD TrueSTEAM with TrueIAQ control			
/PIAQ	9-GPD TrueSTEAM with VisionPRO IAQ control			
)G115	9-GPD TrueSTEAM with TrueIAQ control			
18908	9-GPD TrueSTEAM with H8908 manual control			
/PIAQ	6-GPD TrueSTEAM with VisionPRO IAQ control			
)G115	6-GPD TrueSTEAM with TrueIAQ control			
18908	6-GPD TrueSTEAM with H8908 manual control			

	Accessories
umber	Description
7-001	10' remote-mount kit
7-002	20' remote-mount kit

# **TrueSTEAM**<sup>™</sup> A Quantum Leap In Application And Performance



## **Control Options**

Choose the humidity control option that is right for your customer. TrueSTEAM<sup>™</sup> humidification systems can be controlled using:

VisionPRO<sup>®</sup> IAQ Total

Home Comfort System

temperature, humidification,

TrueIAQ<sup>™</sup> Indoor Air

For automatic control of humidity

based on both inside and outside temperatures. Provides homeowner

with advanced humidity sensing

and programming capabilities.

levels only. Allows homeowner

to adjust settings as needed.

Control

**Quality Control** 

from a single device.

dehumidification and ventilation

For integrated control of the home's







SQUARE

ARI\* Re TrueS Ti

TrueS Tr TrueS Tr

### Part Nu HM512V HM512D HM509V HM509D HM509H HM506V HM506D

HM506H

Part Nu

**Manual Humidity** For simple control of humidity

5002491 5002491



### Which Model Do I Need?

Choose the Honeywell TrueSTEAM model that's right for your application using the table below.

E FEET OF SPACE	500	1,000	1,500	2,000	2,500	3,000
commended Output elivery (GPD)	0.1	2.2	4.4	6.5	8.6	11.7
STEAM HM512 — rue 12 Gallons						
STEAM HM509 — True 9 Gallons						
STEAM HM506 — Tue 6 Gallons						

TrueSTEAM Humidification System				
ımber	Description			
/PIAQ	12-GPD TrueSTEAM with VisionPRO IAQ control			
)G115	12-GPD TrueSTEAM with TrueIAQ control			
/PIAQ	9-GPD TrueSTEAM with VisionPRO IAQ control			
)G115	9-GPD TrueSTEAM with TrueIAQ control			
18908	9-GPD TrueSTEAM with H8908 manual control			
/PIAQ	6-GPD TrueSTEAM with VisionPRO IAQ control			
)G115	6-GPD TrueSTEAM with TrueIAQ control			
18908	6-GPD TrueSTEAM with H8908 manual control			

	Accessories
ımber	Description
7-001	10' remote-mount kit
7-002	20' remote-mount kit

www.forwardthinking.honeywell.com